


径向轴向充油表



| <div>mm</div> <div>size</div> | A     | B    | C     | D    | E       | F    | G    | T    |
|-------------------------------|-------|------|-------|------|---------|------|------|------|
| 40                            | 47.0  | 41.0 | 66.0  | 26.0 | Hex11.0 | 50.0 | 27.0 | 1/8' |
| 50                            | 57.5  | 51.5 | 81.0  | 30.0 | Hex14.0 | 58.5 | 30.0 | 1/4' |
| 63                            | 68.0  | 61.5 | 91.5  | 30.0 | Hex14.0 | 58.5 | 30.0 | 1/4' |
| 75                            | 82.0  | 74.5 | 111.5 | 32.0 | Hex17.0 | 64.5 | 30.0 | 3/8' |
| 100                           | 108.5 | 99.0 | 137.0 | 36.0 | Hex22.0 | 69.0 | 36.0 | 1/2' |